

Mobil Phone Spy Camcorder----The ONLY ONE in the World

Thanks for Purchasing this product,which is the first HD Camcorder Mobile Phone in the World.It is with a few different USEFUL Functions as HD Video Function,HD Resolution Image Function,Quality Audio,Motion Detection,Sound Control ect.

This product is suitable for: reporters, emergency records, fragments of life records, records recreation, sports records, records of teaching aids, home security monitoring, law enforcement forensic evidence, the travel records of human scenery, outdoor adventure records, auxiliary memory.

<1> Construction



<2> Operation

1. On/Off

1) Turn On

- Press the Button, No.1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word "Welcome on Screen"

2) Turn Off

- Press the Button, No.1 for 2 seconds
- The Mobile Vibrates one time
- The Blue Indicator is Off.

2. Video

- Press the Button, No. 1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word “Welcome on Screen”
- Press the Button, No. 2, then release it
- The Mobile Vibrates one time
- There is a red sign on Down-Left of screen twinkling
- Press the Button, No. 2 again to stop the video

3. Shooting

- Press the Button, No. 1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word “Welcome on Screen”
- Press the Button, No. 3, then, release it.
- The Mobile Vibrates one time
- The screen flashes one time

4. Record Audio

- Press the Button, No. 1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word “Welcome on Screen”
- Press the Button, No. 6, then, release it
- The mobile vibrates one time
- There is time set, it starts to record Audio now.
- Press the Button, No. 6, then release it
- The mobile vibrates one time
- It gets out from this function after it saves the file.

5. Motion Detection

- ◆ Press the Button, No. 1 for 2 seconds, release it.
- ◆ The Mobile Vibrates one time
- ◆ The Blue Indicator is burning.
- ◆ There is the word “Welcome on Screen”
- ◆ Press the Button, No. 5, then, release it
- ◆ The Mobile vibraes one time
- ◆ The Motion Detection functions is on

Notice

- If there is something moving in the working area, it starts to take video with audio for 6 seconds, then, saves one file.
- If the objects stops moving within 6 seconds, the camera is still taking video with audio for 6 seconds and saves one file, then, stops taking.
- After it saves this file, if there is an other moving, it starts to work again, and so on.

6, Webcam

- Install the Drive Program in CD
- Turn Off the Mobile
- Connect the Mobile and PC with original USB Cable

Notice

This Function is only for Windows Operation System!

7, Movable Disc

- Turn Off the Mobile
- Connect the Mobile and PC with Original USB Cable

8, Time Reset

- Press the Button, No.1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word "Welcome on Screen"
- Press the Button, No. 8
- There is the Menu on Screen
- Operation the Replay Button, No.11 to change the time.

9, Turn Off or Turn On the Screen

Press the Button, 4, then, release it to Turn on or Turn off the Screen

10. Recharge

- Press the Button, No.1 for 2 seconds, release it.
- The Mobile Vibrates one time
- The Blue Indicator is burning.
- There is the word "Welcome on Screen"
- Connect the Mobile and power source with original USB Cable

<3> Parameters

Item	Specifications
Video Form	AVI
Image Code	MEPG
Video Resolution	1280*960
Software	mainstream operating system comes with audio and video playback software
Image Form	JPG
Support System	Windows me/2000/xp/2003/vista; Mac os 10.4; Linux;
Recharge Voltage	DC-5V
Transfer Interface	MINI 8 Pin USB
Battery	Li-ion Battery

<4> Notice

- This product can not be used for any unlawful purpose, or peril.
- Please recharge it if you do not use it for long time.
- Working Temperatur:0-40° C
- Do not use it in Dust Place
- Please do not subject it to strong impact or vibration
- do not use in strong magnetic or electric place.
- Unknown other matters please contact your local dealer